

# Textiles Knowledge Organiser



Place the thread on the holder and guide under the plastic hook and down channel 1


Take the thread around number 2 and then up the channel to number 3.

Turn the hand wheel towards you and make sure the metal take up lever is visible.

Guide the thread through the take up lever and back down the channel to number 4.

Guide the thread behind the metal bar above the needle. This helps keep the thread in place when you are sewing.

Thread the needle from the front to the back



Place the bobbin in the case in an anticlockwise/backwards direction.

Guide the thread into the first notch at the bottom and then round to the second notch on the left.

Hold the thread from the needle and turn the handwheel towards you slowly. The thread from the needle will catch the thread from the bobbin.

Pull the thread from the bobbin up on top next to the thread from the needle. Replace the glass cover on and you are ready to sew.

